



## Install Keil MDK Version 5 – [www.keil.com/mdk5/install](http://www.keil.com/mdk5/install)

Download and install MDK Core and add these Software Packs:

- **Keil::SAM-V\_DFP** – Atmel SAM V7x Series Device Support
- **Keil::SAM-ESV7\_SFP** – Atmel SAM E/S/V7x Software Foundation (HAL, Driver, BSP)

Verify the installation using example projects provided in the Software Packs:

- Connect the board's **Debug & Power** port to your computer using a Micro USB cable
- Windows will recognize the USB device and install the required drivers automatically.

## More Information

- Getting Started User's Guide [www.keil.com/gsg](http://www.keil.com/gsg)
- ARM Cortex-M7 Support [www.keil.com/mdk5/cortex-m7](http://www.keil.com/mdk5/cortex-m7)

## Related Products

- MDK Version 5: [www.keil.com/mdk5](http://www.keil.com/mdk5)
- MDK-Professional Middleware: [www.keil.com/mdk5/middleware](http://www.keil.com/mdk5/middleware)
- ULINK Family of Debug Adapters: [www.keil.com/mdk5/ulink](http://www.keil.com/mdk5/ulink)